

1. CONNECTION DIAGRAM


GRAMEYER


For single phase power supply equipment connect the filter in parallel with the power supply terminals, following the proper phase and neutral connections to the regulator.

RC FILTER

Note: All dimensions in millimeters.

SIDE VIEW





Rev.: 00 of 2009/03/10 - GGEN03618 • For more information, please check the operation and installation manual of the equipment.