

11 SPARE PARTS LIST

No.	DESCRIPTION	2540 EHS	3870 EHS
1.	Pressure gauge +30 –60 1.5"	GAU029-0009	GAU029-0009
2.	Main switch	ELE035-0012	ELE035-0012
3.	Circuit breaker 20A/3phase	—	ELE035-0053
4.	Circuit breaker 25A/1phase	ELE035-0060	—
5.	Cut-Off thermostat	THE005-0008	THE005-0008
6.	Door Seal	GAS080-0003	GAS080-0004
7.	Water reservoir	RES075-0004	RES075-0004
8.	Water reservoir – complete	CMT240-0056	CMT240-0056
9.	Water reservoir seal	GAS080-0007	GAS080-0007
10.	Float switch	THE007-0001	THE007-0001
11.	Float switch	THE007-0003	THE007-0003
12.	Fuse holder, mini ¼*32	ELE035-0002	ELE035-0002
13.	Fuse 1.25A SB	ELE035-0055	ELE035-0055
14.	Safety valve holder	CMT100-0002	CMT100-0002
15.	Air release valve (black)	CMT100-0006	CMT100-0006
16.	Safety valve ¼ - 40 psi	SVL029-0004	SVL029-0004
17.	Water level vessel	PIP100-0001	PIP100-0001
18.	Long water level electrode - complete	CMT196-0005	CMT196-0005
19.	Short water level electrode- complete	CMV196-0001	CMV196-0001
20.	Steam trap Spiral ¼	—	ARM100-0057
21.	Solenoid 1/4 x 4.5	SOL026-0005	SOL026-0005
22.	Solenoid 1/4 x 3	SOL026-0004	SOL026-0004
23.	Solenoid 1/4 x 6	SOL026-0006	SOL026-0006
24.	Drainage valve complete	VLV170-0066	VLV170-0066
25.	O-Ring (drain valve) 10 x 2.5	SRV000-0224	SRV000-0224
26.	O-Ring (drain valve) 6 x 2	SRV000-0232	SRV000-0232
27.	Nut CTOT84-5010-02	CMT240-0020	CMT240-0020
28.	Ring for drain valve	CMT240-0003	CMT240-0003
29.	Bronze needle valve 1/4	VLV170-0022	VLV170-0022
30.	Plunger for solenoid 4 mm	SOL026-0015	SOL026-0015

12 VALVES NUMBERING

The valves in the drawing and the manual are numbered according to their function. The following list includes all the valve numbers that are in use in this manual

			Size mm	
			2540	3870
1.	FEED WATER	13. Feed water – cool fast exhaust	3	3
		14. Feed water – to reservoir	2.4	4.5
		15. Feed water – to vacuum pump	4.5	4.5
2.	MINERAL FREE WATER	21. Mineral free water - inlet	3	4.5
4.	AIR	43. Filtered air - inlet	3	3
5.	VACUUM	52. Vacuum - to pump	4.5	4.5
7.	EXHAUST	73. Fast exhaust	4.5	4.5
		74. Slow exhaust	3	3
9.	STEAM	93. Steam – to chamber	ASCO 1/4" 12VDC	ASCO 1/4" 12VDC

